

Headphones



Jussi Rämö

Acoustics Lab, Dept. Signal Processing and Acoustics, Aalto University



Aalto University
School of Electrical
Engineering

11 March, 2019


Headphones

Basic operating principles same as loudspeakers and microphones


- Dynamic, electrostatic, (and planar magnetic)




Stax SR-L700



Headphones vs. Loudspeakers



Inter-aural time difference (ITD)



Inter-aural level difference (ILD)



Loudspeaker listening

- Effects of the room and listeners head and body are included.
 - Binaural cues (ITD and ILD) are preserved.
- All speakers are heard with both ears.



Headphones vs. Loudspeakers

Headphone listening

- Effects of the environment and the listener's body are lost,
- Almost perfect channel separation,
 - Poor externalization—Sounds localize inside the head
- Often isolates listener from their surroundings,
 - Personal,
 - Less social,
 - Dangerous in certain situations.





Stereo Widening for Headphones



O. Kirkeby, A Balanced Stereo Widening Network for Headphones, AES 22nd Int. Conf., 2002

Stereo Widening for Headphones





O. Kirkeby, A Balanced Stereo Widening Network for Headphones, AES 22nd Int. Conf., 2002

HRTF

Head Related Transfer Function



- Transfer function in free field from a point source to the ear canal entrance or ear drum.
- Can be used to reproduce virtual loudspeakers over headphones
 - Multi-channel audio,
 - Measurements from loudspeaker positions,
 - Often some artificial reverb is added.

Virtual loudspeakers




HRTF - Head Tracking


When the user turns their head when wearing headphones



Typical listening situation









No head tracking




With head tracking


HRTF - Example Measurements




Headphone Types




Circum-aural



Supra-aural



Intra-concha



In-ear

Additional types/features

- Active noise control (ANC),
- Wireless or truly wireless



Headphone Types



Circum-aural



Supra-aural



Intra-concha




In-ear

Measuring Headphones

Headphones are measured using a coupler, such as a dummy head or an ear canal simulator

- Headphones are designed to sound good when worn properly.
- A coupler simulates the acoustic properties of a human ear—Acoustic load.
- ITU-T Recommendation P.57: Artificial Ears
 - Type 3.3. simulator often used
 - Works with all headphone types
- Microphone (often) at the ear drum position.
 - Drum Reference Point (DRP)






Measuring Headphones

The ear canal simulator standardized in IEC 60318-4

- Cylindrical central volume with the length and diameter similar to an average human ear canal.
- Different resonators connected to the central volume.
- Microphone at the end of the cylindrical volume.
 - DRP
- Measurements and calibration according to the ITU-T Recommendation P.57




Measuring Headphones



Positioning of the Headphones


Correct fitting is extremely important


An in-ear headphone fit different fitting



Positioning of the Headphones

- ITU-T Recommendation P.380: Electro-acoustic measurements on headsets
 - “Due to the sensitivity of the test results to the headset positioning, the tests shall be repeated at least 5 times by completely repositioning the headset...”





Audio Engineering Society
Convention Paper 8147

Presented at the 128th Convention
2010 May 22–25 London, UK

The papers at this Convention have been selected on the basis of a submitted abstract and extended precis that have been peer reviewed by at least two qualified anonymous reviewers. This convention paper has been reproduced from the author's advance manuscript, without editing, corrections, or consideration by the Review Board. The AES takes no responsibility for the contents. Additional papers may be obtained by sending request and remittance to Audio Engineering Society, 60 East 42nd Street, New York, New York 10165-2520, USA; also see www.aes.org. All rights reserved. Reproduction of this paper, or any portion thereof, is not permitted without direct permission from the Journal of the Audio Engineering Society.

Audibility of headphone positioning variability

Mathieu Paquier¹, Vincent Koehl¹

¹University of Brest (UEB), LISyC EA 3883, Centre Européen de Réalité Virtuelle, 25 rue Claude Chappe, 29280 Plouzané, France

Correspondence should be addressed to Mathieu Paquier (mathieu.paquier@univ-brest.fr)

ABSTRACT



This study aims at evaluating the audibility of spectral modifications induced by slight but realistic changes in the headphone position over a listener's ears. Recordings have been performed on a dummy head on which 4 different headphone models were placed 8 times each. Musical excerpts and pink noise were played over the headphones and recorded with microphones located at the entrance of the blocked ear canal. These recordings were then presented to listeners over a single test headphone. The subjects had to assess the recordings in a 3I3AFC task to discriminate between the different headphone positions. The results indicate that, whatever the headphone model or the excerpt, the modifications caused by different positions were always perceived.





“...the modifications caused by different positions were always perceived.”

Magnitude Response

a) Ideal Free Field Pressure Response of Loudspeaker
Measured on-axis with Microphone




b) Response of Same Loudspeaker Measured
at Eardrum (DRP)




Magnitude Response

a) Ideal Free Field Pressure Response of Loudspeaker
Measured on-axis with Microphone



- Ideal free field (anechoic) response of an ideal (flat response) loudspeaker.
 - Reproduces all frequencies equally loud.


b) Response of Same Loudspeaker Measured
at Eardrum (DRP)




- Response of the ideal loudspeaker measured at the ear drum (DRP)
 - Includes the effects of torso, head, pinna, and the ear canal of the dummy head.

Magnitude Response

a) Ideal Free Field Pressure Response of Loudspeaker
Measured on-axis with Microphone




b) Response of Same Loudspeaker Measured
at Eardrum (DRP)




In order for a headphone to sound like an ideal loudspeaker, the magnitude response at the ear drum should look like in Fig. b)




Magnitude Examples



Sennheiser HD 650
- Measured using a dummy head






“Ideal” loudspeaker measured from inside my ear canal (1cm)





Ear canal Resonance



Ear canal acts as a quarter wavelength resonator



©2012, Dan Russell



Ear canal Resonance




Ear canal acts as a quarter wavelength resonator
Tube with one end closed

$$f = \frac{c}{4l}$$


$$f = 3 \frac{c}{4l}$$

$$l = \frac{c}{4f} = \frac{343 \text{ m/s}}{4 \cdot 2900 \text{ Hz}} = 2.96 \text{ cm}$$








Ear
drum





Measurements








Measurements — Circum aural








Measurements — Supra aural








Measurements — Intra concha



Measurements — In ear




Measurements — In ear 2



In-Ear Headphone Properties

Half wavelength resonator (Instead of a quarter wavelength)


- In-ear headphone closes the other end of the tube
 - Tube that is closed at both ends
- Acts as a half-wavelength resonator
 - Creates an **unnatural** half-wavelength resonance
 - Kills the **natural** quarter-wavelength resonance
 - Has to be reintroduced by design



In-Ear Headphone Properties

Pressure Chamber Principle



- Affects low (and middle) frequencies in small, airtight enclosures.
 - Headphone driver pumps the air inside the ear canal cavity producing a sound pressure proportional to the driver excursion.
 - Sound pressure is distributed uniformly in the volume.
- ➔ High SPLs at low frequencies



In-Ear Headphone Properties

Occlusion Effect

- Refers to a situation where one's ears are blocked by headphones and their own voice sounds loud and hollow.
 - Due to the bone conducted sounds that are conveyed to the ear canals.
 - Headphone blocks airborne sound.
- The occlusion effect is experienced as annoying and unnatural.




Measuring Isolation

The difference between the


- **open ear** response, and
- the response when **wearing headphones,**

with external sound source.







Measuring Isolation




Isolation depends on the angle of the sound source




Isolation Measurements




Isolation — ANC



Use Cases for Headphones



Auditory Masking



Auditory Masking

Masking occurs when one sound affects the perceived loudness of another sound

- Masking threshold is the SPL of a maskee necessary to be just audible in the presence of a masker.
- Masker can hide the maskee completely or partially
 - Partial masking reduces the loudness of a target sound, but does not mask it to be inaudible.
- Usually evaluated using critical bands (Bark, ERB).



Magnitudes and Isolations



Sennheiser HD 650



Nokia WH-500



iPhone (old)



Sennheiser CX300


Music

Noise

Music +
Noise

Headphone Simulation in Noise

- The ambient noise isolation capability of headphones has become an important design feature,
 - mobile usage of headphones takes place in noisy listening environments.
- Auditory experience achieved with a certain pair of headphones cannot be evaluated solely by listening to the headphones in a quiet environment.



Audio Engineering Society
Convention Paper

Presented at the 132nd Convention
2012 April 26–29 Budapest, Hungary


This paper was peer-reviewed as a complete manuscript for presentation at this Convention. Additional papers may be obtained by sending request and remittance to Audio Engineering Society, 60 East 42nd Street, New York, New York 10165-2520, USA; also see www.aes.org. All rights reserved. Reproduction of this paper, or any portion thereof, is not permitted without direct permission from the Journal of the Audio Engineering Society.

Signal Processing Framework for Virtual Headphone Listening Tests in a Noisy Environment

Jussi Rämö¹ and Vesa Välimäki¹

Headphone Simulation in Noise

HD650 were equalized to have a flat magnitude response at DRP



Audio Engineering Society
Convention Paper

Presented at the 132nd Convention
2012 April 26–29 Budapest, Hungary

This paper was peer-reviewed as a complete manuscript for presentation at this Convention. Additional papers may be obtained by sending request and remittance to Audio Engineering Society, 60 East 42nd Street, New York, New York 10165-2520, USA; also see www.aes.org. All rights reserved. Reproduction of this paper, or any portion thereof, is not permitted without direct permission from the Journal of the Audio Engineering Society.

Signal Processing Framework for Virtual Headphone Listening Tests in a Noisy Environment

Jussi Rämö¹ and Vesa Välimäki¹

Perceived Response in Noise

- Real-time simulator illustrating how background noise alters the timbre of music in the presence of noise.
- Based on auditory masking models and isolation capabilities of different headphones.
 - Masking threshold estimation
 - Partial masking estimation
- Components of the music that are masked are suppressed.

AES 45TH INTERNATIONAL CONFERENCE, Helsinki, Finland, 2012 March 1–4

Perceptual Frequency Response Simulator for Music in Noisy Environments

Jussi Rämö¹, Vesa Välimäki¹, Mikko Alanko¹, and Miikka Tikander²

¹*Aalto University, Department of Signal Processing and Acoustics, P.O. Box 13000, FI-00076 AALTO, Espoo, Finland*

²*Nokia Corporation, Keilalahdentie 2-4, P.O. Box 226, FI-00045 NOKIA GROUP, Espoo, Finland*

Correspondence should be addressed to Jussi Rämö (jussi.ramo@aalto.fi)

ABSTRACT



A perceptual simulator for music in noisy environments is described. The listening environments where people use their headphones have changed from quiet indoor environments to more noisy outdoor environments. The perceptual simulator utilizes auditory masking models and the isolation capabilities of different headphones to simulate the auditory masking phenomenon. A real-time demonstrator using Matlab and Playrec was implemented, which illustrates how the background noise alters the timbre of the music. It can be used with either headphones or loudspeakers. Informal listening tests showed that the simulator is operating correctly in most cases. However, when there is great amount of energy at the lowest frequencies of the background noise, the masking threshold is predicted to be too high.

Perceived Response in Noise

Implemented with a high-order graphic equalizer


- 3 cascaded 4th-order sections for each critical band

4th-order section




Perceived Response in Noise

Example analysis of a 200 ms frame




Perceptual EQ

Perceptual Headphone Equalization for unmasking music in noisy listening environments.



Ref. Rämö et al. ICASSP 2013, Vancouver, Canada

Perceptual EQ



References

- J. Rämö. “Equalization Techniques for Headphone Listening,” *Doctoral Dissertation*, Aalto University, Espoo, Finland, 2014.
- J. Rämö. “Evaluation of an Augmented Reality Audio Headset and Mixer,” *Master’s Thesis*, Helsinki University of Technology, Espoo, Finland, 2009.
- O. Kirkeby. “A balanced stereo widening network for headphones,” In *AES 22nd Int. Conf. on Virtual, Synthetic and Entertainment Audio*, Espoo, Finland, pp. 117–120, June 2002.
- G. Lorho. “Subjective evaluation of headphone target frequency responses”, In *AES 126th Conv.*, Munich, Germany, May 2009.
- V. Välimäki, A. Franck, J. Rämö, H. Gamper, and L. Savioja. “Assisted Listening Using a Headset: Enhancing audio perception in real, augmented, and virtual environments,” *IEEE Signal Processing Magazine*, Vol 32, No. 2. pp. 92–99, Feb. 2015.
- J. Rämö, V. Välimäki, M. Tikander, “Perceptual Headphone Equalization for Mitigation of Ambient Noise,” *IEEE Int. Conf. Acoust., Speech and Signal Process.*, Vancouver, Canada, May 2013.
- J. Gómez Bolaños, V. Pulkki, “*HRIR Database with Measured Actual Source Direction Data*,” San Francisco, CA, Oct. 2012.