

MS-E2112 Multivariate Statistical Analysis (5cr)

Lecture 4: Measures of Robustness, Robust Principal Component Analysis

Lecturer: Pauliina Ilmonen
Slides: Ilmonen/Kantala

Contents

Lecturer:
Pauliina Ilmonen
Slides:
Ilmonen/Kantala

Measures of Robustness

Influence Function

Empirical Influence Function

Breakdown Point

Robust PCA

References

Measures of
Robustness

Influence Function

Empirical Influence
Function

Breakdown Point

Robust PCA

References

Measures of Robustness

Measures of
Robustness

Influence Function

Empirical Influence
Function

Breakdown Point

Robust PCA

References

Robust Statistical Methods

Lecturer:
Pauliina Ilmonen
Slides:
Ilmonen/Kantala

Measures of
Robustness

Influence Function

Empirical Influence
Function

Breakdown Point

Robust PCA

References

In statistics, robust methods are methods that perform well – or do not perform too poorly – in the presence of outlying observations.

Robust Statistical Methods, Example

Lecturer:
Pauliina Ilmonen
Slides:
Ilmonen/Kantala

Mean vs median...

Measures of
Robustness

Influence Function

Empirical Influence
Function

Breakdown Point

Robust PCA

References

Measures of Robustness

Lecturer:
Pauliina Ilmonen
Slides:
Ilmonen/Kantala

Measures of
Robustness

Influence Function

Empirical Influence
Function

Breakdown Point

Robust PCA

References

Let x denote a random variable or a random vector with a cumulative distribution function F_x , and let $X = \{x_1, x_2, \dots, x_n\}$, where x_1, x_2, \dots, x_n are n independent and identically distributed observations from the distribution F_x . Consider functional $Q(F_x)$ (or $Q(F_n)$). We wish to measure **robustness** of that functional.

Influence Function

Measures of
Robustness

Influence Function

Empirical Influence
Function

Breakdown Point

Robust PCA

References

Influence Function

Lecturer:
Pauliina Ilmonen
Slides:
Ilmonen/Kantala

Influence function measures the effect on functional Q when the underlying distribution deviates slightly from the assumed one.

$$IF(y, Q, F_x) = \lim_{0 < \varepsilon \rightarrow 0} \frac{Q((1 - \varepsilon)F_x + \varepsilon\delta_y) - Q(F_x)}{\varepsilon},$$

where δ_y is the cumulative distribution function having all its probability mass at y i.e.

$$\delta_y(t) = \begin{cases} 0, & t < y, \\ 1, & t \geq y. \end{cases}$$

Measures of
Robustness

Influence Function

Empirical Influence
Function

Breakdown Point

Robust PCA

References

Influence Function

Lecturer:
Pauliina Ilmonen
Slides:
Ilmonen/Kantala

Measures of
Robustness

Influence Function

Empirical Influence
Function

Breakdown Point

Robust PCA

References

Influence function measures the effect of point-mass contamination, and thus it is considered as a measure of **local robustness**.

A functional with **bounded influence function** (with respect to for example L_2 norm) is considered as robust and desirable.

Influence Function, Examples

Lecturer:
Pauliina Ilmonen
Slides:
Ilmonen/Kantala

Measures of
Robustness

Influence Function

Empirical Influence
Function

Breakdown Point

Robust PCA

References

- Mean: $IF(y, \mu, F_x) = y - \mu(F_x)$. (Proof...)

Empirical Influence Function

Measures of
Robustness

Influence Function

Empirical Influence
Function

Breakdown Point

Robust PCA

References

Empirical Influence Function

Lecturer:
Pauliina Ilmonen
Slides:
Ilmonen/Kantala

Empirical influence function (also called the sensitivity curve) is a measure of the dependence of the estimator on the value of one of the points in the sample.

The empirical influence function can be seen as an estimate of the theoretical influence function.

Measures of
Robustness
Influence Function
Empirical Influence
Function
Breakdown Point
Robust PCA
References

Empirical Influence Function

Lecturer:
Pauliina Ilmonen
Slides:
Ilmonen/Kantala

Let $X = \{x_1, x_2, \dots, x_n\}$, and let $X_y = \{x_1, x_2, \dots, x_n, y\}$. Now

$$\begin{aligned} IF_E(y, Q, F_n) &= \frac{Q\left(\left(1 - \frac{1}{n+1}\right)F_n + \frac{1}{n+1}\delta_y\right) - Q(F_n)}{\frac{1}{n+1}} \\ &= (n+1)\left(Q\left(\left(1 - \frac{1}{n+1}\right)F_n + \frac{1}{n+1}\delta_y\right) - Q(F_n)\right) \\ &= (n+1)(Q(X_y) - Q(X)). \end{aligned}$$

Measures of
Robustness

Influence Function

Empirical Influence
Function

Breakdown Point

Robust PCA

References

Empirical Influence Function, Example

Lecturer:
Pauliina Ilmonen
Slides:
Ilmonen/Kantala

Measures of
Robustness

Influence Function

Empirical Influence
Function

Breakdown Point

Robust PCA

References

Empirical influence function of the mean...

Breakdown Point

Measures of
Robustness

Influence Function

Empirical Influence
Function

Breakdown Point

Robust PCA

References

Breakdown Point

Lecturer:
Pauliina Ilmonen
Slides:
Ilmonen/Kantala

Measures of
Robustness

Influence Function

Empirical Influence
Function

Breakdown Point

Robust PCA

References

Another very often used measure of robustness is the breakdown point. Whereas influence function measures local robustness, the **breakdown point** can be seen as a **measure of global robustness**.

Breakdown Point

Let $X_n = \{x_1, x_2, \dots, x_n\}$, where x_1, x_2, \dots, x_n are n independent and identically distributed observations from the distribution F_X . Assume that $m < n$ and replace x_1, x_2, \dots, x_m with $x_1^*, x_2^*, \dots, x_m^*$. Let $X_n^* = \{x_1^*, x_2^*, \dots, x_m^*, x_{m+1}, \dots, x_n\}$.

Now, the maximum bias

$$\maxBias(m, X_n, Q) = \sup_{x_1^*, x_2^*, \dots, x_m^*} d(Q(X_n), Q(X_n^*)),$$

where $d(\cdot, \cdot)$ denotes some distance function (for example the euclidian distance).

The finite sample breakdown point is now given by

$$BP(Q, n) = \min_m \left\{ \frac{m}{n} \mid \maxBias(m, X_n, Q) = \infty \right\},$$

and the (asymptotic) breakdown point

$$BP(Q) = \lim_{n \rightarrow \infty} BP(Q, n).$$

Breakdown Point

Lecturer:
Pauliina Ilmonen
Slides:
Ilmonen/Kantala

Measures of
Robustness

Influence Function

Empirical Influence
Function

Breakdown Point

Robust PCA

References

A functional with **large breakdown point** is considered as robust. If $BP(Q) = \frac{1}{2}$, then Q is very robust (according to its breakdown point), and if $BP(Q) = 0$, then Q is very nonrobust. When the value is in between $\frac{1}{2}$ and 0, then it is a matter of taste ;-).

Breakdown Point, Example

Lecturer:
Pauliina Ilmonen
Slides:
Ilmonen/Kantala

Measures of
Robustness

Influence Function

Empirical Influence
Function

Breakdown Point

Robust PCA

References

Mean, covariance matrix, median...

Robust PCA

Lecturer:
Pauliina Ilmonen
Slides:
Ilmonen/Kantala

Measures of
Robustness

Influence Function

Empirical Influence
Function

Breakdown Point

Robust PCA

References

If the data can be assumed to arise from elliptical distribution, then principal component analysis can be robustified by replacing the sample covariance matrix with some robust scatter estimate. The reason for that is that, under elliptical distribution, all scatter estimates do estimate the same population quantity (up to the scale). Note that in general (without ellipticity assumption) this does not hold!

Measures of
Robustness

Influence Function

Empirical Influence
Function

Breakdown Point

Robust PCA

References

Minimum Covariance Determinant (MCD) Method

Lecturer:
Pauliina Ilmonen
Slides:
Ilmonen/Kantala

The determinant (volume) of a covariance matrix, can be seen as a measure of total variation of the data, and it is then called the generalized variance. Data points that are far away from the data cloud increase the volume of the covariance matrix.

Measures of
Robustness

Influence Function

Empirical Influence
Function

Breakdown Point

Robust PCA

References

Minimum Covariance Determinant (MCD) Method

Lecturer:
Pauliina Ilmonen
Slides:
Ilmonen/Kantala

Minimum Covariance Determinant (MCD) method is a well-known method for robustifying the estimation of the covariance matrix, and the mean vector, under the assumption of multivariate ellipticity.

MCD method is based on considering all subsets containing $p\%$ (usually 50%) of the original observations, and estimating the covariance matrix, and the mean vector, on the data of the subset associated with the smallest covariance matrix determinant. This is equivalent to finding the sub-sample with the smallest multivariate spread. The MCD sample covariance matrix, and the MCD sample mean vector, are then defined as the sample covariance matrix (up to the scale), and the sample mean vector, computed over this sub-sample.

Measures of
Robustness

Influence Function

Empirical Influence
Function

Breakdown Point

Robust PCA

References

Under the ellipticity assumption, PCA can be performed using the MCD scatter estimate instead of the traditional sample covariance matrix. MCD estimates are very robust, and thus as a consequence, robust PCA is obtained. Note that MCD is not the only possible robust scatter estimate - there exists several robust scatter estimates that all estimate the same population quantity (up to the scale) under the assumption of multivariate ellipticity.

Measures of
Robustness

Influence Function

Empirical Influence
Function

Breakdown Point

Robust PCA

References

Words of Warning

Lecturer:
Pauliina Ilmonen
Slides:
Ilmonen/Kantala

Measures of
Robustness

Influence Function

Empirical Influence
Function

Breakdown Point

Robust PCA

References

Some Words of Warning

Lecturer:
Pauliina Ilmonen
Slides:
Ilmonen/Kantala

- It is possible that a functional Q has bounded influence function, but its breakdown point is 0!
- Robust PCA, based on some robust scatter matrix, can be performed under the assumption of multivariate ellipticity. If the ellipticity assumption does not hold, instead of estimating the PCA transformation matrix Γ , one may be estimating some other population quantity.

Measures of
Robustness

Influence Function

Empirical Influence
Function

Breakdown Point

Robust PCA

References

Next Week

Lecturer:
Pauliina Ilmonen
Slides:
Ilmonen/Kantala

Next week we will talk about bivariate correspondence analysis (CA).

Measures of
Robustness

Influence Function

Empirical Influence
Function

Breakdown Point

Robust PCA

References

References

Measures of
Robustness

Influence Function

Empirical Influence
Function

Breakdown Point

Robust PCA

References

References I

Lecturer:
Pauliina Ilmonen
Slides:
Ilmonen/Kantala

Measures of
Robustness

Influence Function

Empirical Influence
Function

Breakdown Point

Robust PCA

References

 K. V. Mardia, J. T. Kent, J. M. Bibby, *Multivariate Analysis*, Academic Press, London, 2003 (reprint of 1979).

References II

Lecturer:
Pauliina Ilmonen
Slides:
Ilmonen/Kantala

-  R. V. Hogg, J. W. McKean, A. T. Craig, Introduction to Mathematical Statistics, Pearson Education, Upper Sadle River, 2005.
-  R. A. Horn, C. R. Johnson, Matrix Analysis, Cambridge University Press, New York, 1985.
-  R. A. Horn, C. R. Johnson, Topics in Matrix Analysis, Cambridge University Press, New York, 1991.

Measures of
Robustness

Influence Function

Empirical Influence
Function

Breakdown Point

Robust PCA

References



P. J. Rousseeuw, Multivariate estimation with high breakdown point, *Mathematical Statistics and Applications* **8** (W. Grossmann, G. Pug, I. Vincze, W. Wertz, eds.), p. 283–297, 1985.



P. J. Rousseeuw, K. Van Driessen, A fast algorithm for the minimum covariance determinant estimator, *Technometrics* **41**, p. 212–223, 1999.