

MEC-E1004 Principles of Naval Architecture

Lecture 9 – Ship Weights and stability

Learning points !

- After the lecture, you will be able to
 - Explain the purpose of classification of ship systems and define classification standards
 - Explain the importance of weight calculations in ship design
 - Define the various stages of a ship weight calculation process and explain how they might be carried out
 - Carry out a preliminary weight assessment of your project ship



Assignment 9 – Weight and stability

- Classify the main components and systems of your ship in accordance with the SFI system (1st and 2nd level only)
- Using the SFI classification, estimate your ship's lightship weight and deadweight (considering its mission). Calculate also the resulting displacement
- Assess the level of uncertainty in your weight calculations and determine a "weight reserve"
- Calculate your ship's vertical centre of gravity (G)



Classification of systems

Question: Why do you think classification of ship systems is needed?



Classification of ship systems

- A functional subdivision/classification of technical ship information
- Needed for a systematic and standardized description of a ship (ship specification), for the purpose of
 - Weight assessment (using statistics)
 - Price estimation (using statistics)
 - Production planning and progress monitoring
 - Work breakdown system: Blocks Grandblocks Areas -Systems



Image credit Turun Sanomat

• Used by shipyards, ship owners, suppliers, subcontractors,...



Classification of systems

• Systems

- Hull, propulsion machinery, outfitting, etc.
- Logical, but can be difficult to define properly
- Disciplines
 - Steel, electricity, pipes, etc.
 - Suitable for hull parts but difficult for outfitting
- Ship part
 - Bow, stern, deck house, etc.
 - Might lead to deep hierarchies



Image credit Kongsberg



Classification of systems

Were developed to provide to the yards and to the companies involved in the management and operation of ships tools to support

- Ship Specifications
- Estimative of ship building (or repair) costs
- Estimative or determination of the Lightship Weight
- Procurement of materials, equipment and services.

Three basic systems:

- MARAD- MARitime ADministration, used by the U.S.A. administration
- **SWBS-** Ship Work Breakdown Structure, used by the USA Navy.
- SFI- developed by the Ship Research Institute, from Norway



SWBS and the SFI are organized in a number of main groups, wich are divided in groups, sub-groupse so on. The MARAD system is less defined and complete in its structure. In each of these systems, a classification number is assigned to each item or group of items of the ship, according to a tree structure.



The SFI system

Code letter system

- Also referred to as Littera systems
 - Littera (Latin word !) is a code letter or number describing an object

Example of code letter systems

- <u>SFI</u>Coding & Classification System
 - A system for developed and published by the Norge Skips Forsknings Institutt (NSFI) from Noruway, and which is now property of XANTIC (www.xantic.net).
 - Shipyard specific



Image credit SFI Group System

The SFI system defines 10 main groups (only 8 are currently utilized for Ships)

- o. (reserved)
- 1. Ship General
- 2. Hull
- 3. Equipment for Cargo
- 4. Ship Equipment
- 5. Equipment for Crew and Passengers
- 6. Machinery Main Components
- 7. Systems for Machinery Main Components
- 8. Ship Common Systems
- 9. (reserved)



Classification of systems



Image credit SFI Group System



Weight calculation

Question 1 : Can you mention any ship weight calculation related terms? Question 2 : What's the purpose of weight calculations in ship desing?



Important terminology

Lightship weight (\approx a ships own weight)

- The weight of a ship in metric tons without cargo, fuel, lubricating oil, ballast water, fresh water and feed water in tanks, consumable stores, passengers and crew and their belongings
 - Includes standard outfitting, inventory according to the List of Inventory, spare parts according to the Class Society requirements and with liquids in engine room systems
 - Does not include loose container lashing equipment, spare parts in excess of rule requirements, provision stores, crew and effects, fuel oil, diesel oil, lubricating oil, fresh water, ballast water in tanks

Deadweight (\approx the weight of what a ship is carrying)

- Defined as the difference between an actual displacement and the lightship weight
 - SOLAS: "Deadweight is the difference in tones between the displacement of a ship in water of a specific gravity of 1.025 at the load waterline corresponding to the assigned summer freeboard and the lightweight of the ship"
 - Expressed in either long tons or metric tons
- A measure of ship's ability to carry various items: cargo, stores, ballast water, provisions and crew, etc.

Displacement (= Lightship weight + Deadweight = Total ship weight)

- The weight of water displaced by this vessel at any waterline
 - The product of the volume of its underwater portion and the density of the water in which it floats
- Expressed in long/imperial tons (1 long ton \approx 1.01605 metric tons)



Important terminology

- Contract deadweight
 - As specified by the shipbuilding contract
- Deadweight acceptance limit
 - Value below of which a shipyard has to compensate the owner (€/ton)
- Deadweight rejection limit
 - Value below of which the owner has the right to reject the ship
- Legal deadweight
 - Value resulting from agreed on design modifications



Load line mark. Image credit boatdesign.net



Why weight calculations?

Weight calculations aim to determine a ship's weight, center of gravity (*in horizontal, vertical and transversal directions*), and weight distribution

- Help make sure that a ship floats and is stable
- Help determine a ship's
 - Floating position (trim)
 - Intact, damage, and dynamic stability
 - Maneuverability
 - Power demand
 - Seakeeping
 - ...
- Therefore, they are needed in the determination of a ship's
 - Hull proportions and lines
 - Cargo carrying capability
 - Hull girder strength
 - Resistance / Propulsion power demand
 - Building costs (weight and building costs are strongly related)

→ Weight calculation errors might have very significant technical and economic consequences



Weight calculation process

Weight calculations are carried out throughout the whole ship design and building phase

- The accuracy of the calculations increases as the design and building processes advances
 - Preliminary weight assessment \rightarrow Intermediate weight calculation \rightarrow Official weight calculation
- The weight calculation process can be roughly divided into
 - Rough preliminary weight assessment
 - **Preliminary** calculations
 - Intermediate/ control calculation
 - Final / Official calculations
 - **Post-calculation** to study i.e. how the weight changed during the building process
 - Statistical analysis → weight statistics for future shipbuilding projects
 - Inclining experiment to validate the weight calculations



Rough preliminary weight assessment

Simplified estimation based on statistics

- Empirically determined "Rule of thumb formulas" Hull weight = factor x LBH
 - Machine weight = factor x power
 - Outfitting weight = factor x LBH
 - Interior weight = factor x interior area

Using empirical formulas, the calculation accuracy depends on the quality of the applied statistics

- Empirical values are accurate only for designs that are similar to those based on which they were determined
- Standardized ship system / equipment / part categories needed





Ship design for efficiency and economy/H. Schneekluth and. V. Bertram. — 2nd ed. p. cm. Includes bibliographical references and index. ISBN 0 7506 4133 9.

Preliminary weight calculations

Can be carried out by dividing a ship's lightweight into parts whose weights are estimated using

- Empirically determined weight coefficients
- Volumes and areas determined based on the ship's (preliminary) general arrangement
- Known/estimated weights of individual major components
- Calculation time: a few days

Example formulas:

Ship part	Weight formula
Aft ship	C 211x LBH
Fore ship	C 212x LBH
Double bottom	C213 x LBH
Bulkhead	C214 x A
Deck structures	C215 x A
Side structures	C216 x L(B + 2H)
Superstructure	C 221 x V
Funnel structure	C 223 x V
Machine platforms	C23 x LBH



Intermediate & final weight calculations

Carried out based on

- Weight coefficients C determined accurately from
 - Final general arrangement
 - Construction / as-built drawings
 - System drawings
- Measured/given weights of specific ship components / blocks

The related detailed calculations produce a lot of data

General constants/assumptions

- Density of the seawater
 - Baltic Sea 1,01 ton/m3,
 - North Sea 1,025 ton/m3
 - Helsinki 1,0038 ton/m3, see Finnish maritime law p.960
- Density of oils (at approx. 20 C)
 - Heavy fuel 0,93 ton/m3
 - Lubricant 0,91 ton/m3
 - Diesel fuel 0,83 ton/m3
- Steel density
 - 7,8 ton/m3 (unmanufactured)
 - 8,0 ton/m3 (manufactured)



Inclining experiment

Performed in dock before sea trial by placing a weight (w) at the ship side (one side at a time) and my measuring the resulting angle (φ)

- Performed at lightweight displacement (not deadweight !)
- Validation of weight calculations
 - Determination of a ship's actual weight and center of gravity



https://www.youtube.com/watch?v=nebKCMCg0IM



Weight calculations – Risk factors

- An innovative (new) ship type (or an inexperienced designer)
- A small Deadweight/Displacement ratio in combination with a complex lightweight composition
 - Relative small mistakes might have huge consequences
- An unclear division of responsibilities between designer and builder
- A highly competitive shipbuilding market situation
- Economic troubles at the shipyard
 - Efforts to reduce man-hours \rightarrow Mistakes



. . .

Weight calculation – Calculation errors

Weight calculation errors may be critical if

- Ratio between deadweight and displacement is small
 - E.g. icebreakers
- Ratio between outfitting weight and total lightweight is large
 - E.g. cruise ships, ferries

The risk of calculation errors can be minimized by

- Order of magnitude assessments
- Use of statistics, comparisons
- Performing separate calculations using different methods
- By adding weight reserves
 - The lightweight and the height of center of gravity often increase during the building process (e.g. stiffeners are bigger than planned)
 - Needed to allow for possible design modifications as requested by the owner
 - The lightweight reserve can vary depending on the ship type, the shipyard experience, and ship owner
- By adding "scantling reserves"





Lightship weight / Displacement





Weight calculation reserves

- Weight reserves are expressed as a percentage of a ship's total lightship weight
- Reserves in vertical center of gravity (G) are expressed in meters
- Often determined so that at delivery time, the reserve weight is 0 % and the reserve in vertical center of gravity is 0.1 m
 - A residual reserve for the center of gravity is needed since it is difficult to determine the GM value accurately for the operation environment
- The reserve amount needed is determined considering the Deadweight/Displacement ratio
 - Example (prototype ship with a DWT/ Δ ratio of 0.2-0.3)
 - ✓ Preliminary weight calculations: 15 % weight reserve and 1 m reserve in G
 - $\checkmark\,$ Fixing of lines drawings: 10 % weight reserve and 0.6 m reserve in G
 - ✓ 6 months prior to ship delivery: 3 % weight reserve and 0.3 m reserve in G
- For non-prototype ships (if a sister ship has already gone through the inclining test), smaller reserves are possible



Summary

Classification of systems

- A standardized classification of ship systems and equipment such as the SFI standard is useful for several purposes
 - Act as a check list (Has all components been considered?)
 - Needed for the determination and use of statistics for ship weight calculations
 - Areas/ volume specific weight coefficients

Weight calculations

- Very important as a ship's weight and weight distribution have a very significant impact on its technical and economical performance
- Performed throughout the whole design and building process







Bonus material



Weight calculations - Examples

Vasa

- Launched 1627, capsized and sank on its maiden voyage in 1628
- The original design was determined by the Dutch shipbuilder Henrik Hybertsson using an empirical method
 - The theory of intact ship stability did not yet exist
- Design modifications (e.g. a larger number of cannons) ordered by King Gustaf II Adolf during the building process → Too low freeboard

Ro-pax ferry Berlin /Copenhagen

- Built by P+S Yards for Scandlines
- Ordered 2010, launched for the first time in 2012
- The owner (Scandlines) cancelled the vessels because they were 200 tons overweight
- In 2014 bought Scandlines the ferries from the now bankrupt shipwyard for 31,6 M€ instead of the origianl copntract proce of 184 M€



Image credit Vasamuseet



Image credit Scandlines



Weight calculation

Unit weight for stiffened plate field, in which the plate includes longitudinal stiffeners, longitudinal girders and transverse web frames



$$W = t + \frac{1}{S_{FR}} W_{FR} + \frac{1}{S_{GIR}} W_{GIR} + \frac{1}{S_{STIF}} W_{STIF} [ton/m^2]$$

t – plate thickness [kg/m2] W_{xx} – weight of the component in [ton/m]

