

Aalto University


School of Engineering

MEC-E2004 Ship Dynamics (L)

Lecture 10

Manouvering & Added Resistance

Where is this lecture on the course?



Contents

Aims :

- How the added resistance due to waves and wind can be analysed ?
- How motions of the ship in the plane of sea-surface can be assessed ?

Key topics :

- Added resistance in regular & irregular head long and short waves
- Principles of aerodynamic resistance
- Maneuvering: motion stability, simulation, course-keeping, stability & control

Literature:

1. Lloyd, A.R.J.M, Seakeeping – Ship Behavior in Rough Weather, Ch. 19
2. Liu, S. and Papanikolaou, A., On the Prediction of the Added Resistance of Large Ships in Representative Seaways, *Ships and Offshore Structures*, 2016.
1. Matusiak, J., "Ship Dynamics", Aalto University
2. Bertram, V., "Practical Ship Hydrodynamics", Ch. 5
3. Lewis, E. V. Principles of Naval Architecture. Vol. 3, Motions in waves and controllability, Ch.9
4. Rawson, K. J., Basic Ship Theory. Volume 2, Ship dynamics and design - Ch.13
5. Molland and Turnock, Marine Rudders and Control surfaces



Assignment 5

□ Grades 1-3:

- ✓ Select book-chapters related with (1) seakeeping design criteria (2) added resistance (3) maneuvering and reflect to your ship
- ✓ Assess seakeeping criteria with some software and assess the performance of the initial design with respect to those
- ✓ Discuss the simplifications made in added resistance/maneuvering modelling and analysis of your ship
- ✓ Select the maneuvering tests to be simulated and justify the selections





□ Grades 4-5:

- ✓ Based on scientific literature, discuss the accuracy of the obtained results
- ✓ Compute the part of added resistance in selected wave conditions in relation to still water resistance & discuss results
- ✓ Discuss what issues you can still improve for your ship in the follow-up courses




-
- Report and discuss the work

Part I : Added Resistance in waves



Added Resistance - Introduction

- ❑ The speed of a ship in calm water is defined by: propeller efficiency, resistance (wave and friction), power of engines.
- ❑ In rough weather the resistance may be changed by the action of waves, current, wind, ice. Loads may also affect performance leading to involuntary loss of speed. A ship can experience a 15-30% resistance increase in a seaway and an effect of this is higher OPEX.
- ❑ Added resistance in waves is the part of a ship's total resistance that is caused by encountering waves. **Calculations of added resistance can be used as an addition to the calm water resistance to predict the total resistance of a ship in a seaway.**




Added Resistance – some challenges

- ❑ Fast, accurate and efficient theoretical prediction models
- ❑ Validation
- ❑ Implementation in operational practice – **sustainable shipping operations**
 - ✓ **Weather margin** where the max. resistance increase due to weather can be predicted, to decide engine installations ?
 - ✓ **Weather routing** which is important due to its economical effect on ship exploitation. It is for instance very important to make good estimations of the time it will take for a ship to travel a route, so the cargo owners know when the ship will arrive in port, minimizing the costs of storage. It is also very important to be able to optimize routes in order to reduce the fuel consumption and emission.
 - ✓ **Performance analysis** – solving the inverse problem : By excluding the influence of stochastic waves in a seaway, we can evaluate a ship's "real" calm water resistance. This "real" calm water resistance can be used as a measurement of the ship's performance over time. The ship owners could use this information to determine the value of a ship, how often it should be docked for antifouling, and other factors.


Added Resistance in Regular Waves

- ❑ A ship operated in regular head waves has changing resistance.
- ❑ The mean value of the resistance will be always larger than that of calm water resistance.
- ❑ When a ship is oscillating due to waves, it supplies energy to the surrounding water, energy that will increase the resistance.
- ❑ This energy is primarily transmitted **with the waves radiating from the ship.**
- ❑ Energy is also transmitted to the surrounding water by waves generated by the forward speed of the ship. This is referred to as the **calm water resistance**



Added Resistance in Regular Waves

- ❑ Energy comes from hydro-damping released following oscillations in waves. Damping is dominating heave- and pitch motions, which are the biggest contributors to added resistance.
- ❑ Thus added resistance can be considered as a non viscous phenomenon and analysis can be based on **potential theory**.
- ❑ **Radiation induced resistance** is dominating when the ship motions are big. This happens in the region of the resonance frequency of heave and pitch motions. The reflection of incident waves is also causing added resistance.
- ❑ **Diffraction induced resistance** is dominating for high wave frequencies, where the ship motions are small.



Key methods

- (1) Gerritsma & Beukelman
- (2) Boese
- (3) Faltinsen

- ❑ **Methods (1) and (2) deal with radiation induced resistance only**
- ❑ **Method (1) is a so-called radiated energy method.** This problem starts out by trying to describe the energy that the oscillating ship transmits to the surrounding water. It is assumed that to maintain a constant forward ship speed, this energy should be delivered by the ship's propulsion plant.
- ❑ **Method (2) is a pressure integration method**, which basically means that the linear pressure in the undisturbed wave is integrated over the ship hull, to obtain a mean force in the heading direction of the ship. It may seem strange that the linear pressure would give a mean force, but it does in this case since the ship hull, where the integration is performed, is moving.
- ❑ **Method (3) only deals with diffraction induced resistance and neglects the ship motions.**


Method (1) : Geritsma and Beukelman

- ❑ Calculate the **radiated wave energy** during one period of oscillation, in regular waves. This is the energy required to create waves, when the ship is oscillating and it is assumed that to maintain a constant forward ship speed, this energy should be delivered by the ship's propulsion plant.
- ❑ The **relative velocity** is the vertical velocity of the water related to a point on the ship. It is evaluated by the expression :

$$V_{z_b} = \left[-V \cdot \eta_5 + i \cdot \omega_e (x_b \cdot \eta_5 - \eta_3) + i \cdot \omega \cdot \zeta_a \cdot e^{-k \cdot \bar{D}} \cdot e^{-i \cdot k \cdot x_b \cdot \cos(\beta)} \right] \cdot e^{i \cdot \omega_e \cdot t}$$


...and the amplitude:

$$|V_{z_b}| = \left| -V \cdot \eta_5 + i \cdot \omega_e (x_b \cdot \eta_5 - \eta_3) + i \cdot \omega \cdot \zeta_a \cdot e^{-k \cdot \bar{D}} \cdot e^{-i \cdot k \cdot x_b \cdot \cos(\beta)} \right|$$





- ❑ The radiated energy can be calculated
$$E = \int_0^{T_e} \int_0^L b' \cdot V_{z_b}^2 \cdot \partial x_b \cdot \partial t$$

assuming the ship progresses diagonally in waves



- ❑ The added resistance is
$$R_{aw} = \frac{-k \cdot \cos(\beta)}{2 \cdot \omega_e} \int_0^L b' \cdot |V_{z_b}|^2 \cdot \partial x_b$$
 this method is very much related to the Strip theory; b' is the sectional damping coefficient for speed, for the different strips.


Added Resistance in Irregular Head Waves




- ❑ Typically the ways to assess added resistance are:
 - ✓ Towing tank tests
 - ✓ CFD tools
- ❑ The range of wave to ship length is around 0.5-2, for large ships we need to go below this range, e.g., 0.15
- ❑ The problem in model scale testing is the low force values to be measured
- ❑ The problem in CFD is that it requires very dense computational mesh

Added Resistance in irregular Head Waves

- ❑ The added resistance in short waves is due to diffraction and reflection effects
- ❑ The added resistance in long waves is due to motions
- ❑ Both of the cases have been discussed in Liu and Papanikolaou (10.1016/j.oceaneng.2015.12.022)



Ocean Engineering 112 (2016) 211–225



Fast approach to the estimation of the added resistance of ships in head waves



Shukui Liu, Apostolos Papanikolaou*

Ship Design Laboratory, National Technical University of Athens, Greece

ARTICLE INFO

Article history:
Received 19 August 2015
Accepted 10 December 2015

Keywords:
Added resistance of ships
Minimum powering in waves
IMO EEDI regulations
Semi-empirical formulas
Level 1 methods
Approximations in short and long waves


ABSTRACT

In this paper we develop and explore various simple semi-empirical formulations for the fast, but satisfactory estimation of the added resistance of ships in head waves. Relevant research work is in the frame of recent IMO-MEPC232(65) EEDI guidelines for the estimation of minimum powering of ships in adverse weather conditions calling for suitable level 1 methods. We consider the effect of main characteristics of ship's hull form, with best fitting of available experimental data for different types of hull forms. A proposed new semi-empirical formula is simplified to the extent that it can be readily calculated using as input merely the speed and main characteristics of the ship and of the wave environment. Extensive validations of the proposed simplified formula for various ship hulls in both regular and irregular waves were carried out and compared to other comparable methods and more complicated approaches to the determination of the added resistance in head waves.

© 2015 Elsevier Ltd. All rights reserved.

Aerodynamic Forces

- ❑ For ship dynamics the hydrodynamic forces are not enough
- ❑ Aerodynamic loads may also play an important role
 - ✓ Strong side wind may disturb ship berthing
 - ✓ gusty side wind may cause large dynamic heeling
 - ✓ Strong head wind may increase resistance
 - ✓ maneuvering qualities of ship
 - ✓ + aerodynamics can cause funnel fumes to land on sundeck of a passenger ship
- ❑ Evaluation of the loads requires of the aerodynamic force coefficients given in the body- fixed co-ordinate system. If in-plane horizontal motion of ship is considered only, then two force components (x- and y-directional ones) and yawing moment coefficient are required
- ❑ The total resistance is $D_c = C_D \frac{1}{2} \rho_A U^2 A_s$
 - ✓ A_s is the cross-sectional area of influence
 - ✓ U and ρ_A the wind speed and air density
 - ✓ C_D the drag coefficient determined by CFD or wind-tunnel tests




Aerodynamic Forces

- The waves are typically present with the wind which increases the aerodynamic drag to:

$$D_w = C_D \frac{1}{2} \rho_A (U + U_w)^2 A_s$$

- And the total drag is then

$$D_{aw} = C_D \frac{1}{2} \rho_A (U_w^2 + 2UU_w) A_s$$




Weather Routing



- ❑ When the added resistance can be predicted for various sea states, we can start to optimize the route for individual journeys
 - ❑ We need to know the wave environment
 - ✓ Scatter diagram
 - ✓ Weather forecasts
 - ❑ We need to know the RAO for added resistance
 - ✓ Measured from the ship
 - ✓ Simulations
 - ✓ Model scale experiments
 - ❑ The RAO x sea state considers, as short time of 0.5-3 hours
 - ❑ The entire journey is set of short term responses
 - ✓ Several simulations are needed to assess the probabilities
 - ✓ Course can be changed based on weather forecasts to save fuel (EEDI)

Table 5—Observed Percentage Frequency of Occurrence of Wave Heights and Periods (Hogben and Lumb data)

Wave height, m	Wave Period T_1 , sec										Total
	2.5	6.5	8.5	10.5	12.5	14.5	16.5	18.5	20.5	Over 21	
0-1	13.7204	3.4934	0.8559	0.3301	0.1127	0.0438	0.0249	0.0172	0.0723	0.3584	19.0291
1-2	11.4889	15.5036	6.4817	1.8618	0.5807	0.1883	0.0671	0.0254	0.0203	0.0763	36.2941
2-3	1.5944	7.8562	8.0854	3.7270	1.1790	0.3713	0.1002	0.0321	0.0091	0.0082	22.9629
3-4	0.3244	2.2487	4.0393	2.9762	1.3536	0.4477	0.1307	0.0428	0.0050	0.0040	11.5724
4-5	0.1027	0.7838	1.6998	1.5882	0.9084	0.3574	0.1443	0.0433	0.0072	0.0049	5.6400
5-6	0.0263	0.1456	0.3749	0.4038	0.2493	0.1200	0.0382	0.0067	0.0027	0.0027	1.3702
6-7	0.0277	0.1477	0.3614	0.4472	0.2804	0.1301	0.0504	0.0113	0.0011	0.0032	1.4605
7-8	0.0084	0.0714	0.1882	0.2199	0.1634	0.0785	0.0353	0.0069	0.0018	0.0034	0.7772
8-9	0.0037	0.0325	0.0856	0.1252	0.1119	0.0558	0.0303	0.0045	0.0027	0.0033	0.4555
9-10	0.0034	0.0204	0.0674	0.1173	0.0983	0.0550	0.0303	0.0173	0.0073	0.0047	0.4220
10-11	0.0005	0.0012	0.0023	0.0031	0.0031	0.0012	0.0005	0.0005	0.0005	0.0005	0.0088
11+	0.0005	0.0007	0.0019	0.0035	0.0002						0.0073
Totals	27.3003	30.3043	22.2415	11.8009	5.0143	1.8493	0.6517	0.2080	0.1306	0.4691	100.000



Part II : Ship Maneuvering





Motivation

- ❑ Ship is a large moving mass that should be carefully controlled
- ❑ Motions are extremely slow
 - ✓ Response time not comparable to cars etc.
 - ✓ Completely halting a ship from full speed might take several nautical miles
- ❑ **Three aspects for good controllability**
 - ✓ Realistic specification and criteria for course keeping, manoeuvring and speed change
 - ✓ Design of hull and control equipment to meet these requirements
 - ✓ Validation with full-scale sea-trials to compare with specification and predictions




Controllability & Motion Stability


- ❑ Controllability covers all aspects related to ship's:
 - ✓ Trajectory
 - ✓ Speed
 - ✓ Orientation
 - ✓ Positioning and station keeping
- ❑ Controllability is typically divided to three areas:
 - ✓ Course keeping and steering, i.e. maintaining steady mean course
 - ✓ Manoeuvring, i.e. changing the direction of the course
 - ✓ Speed changing, i.e. controlled speed change including stopping and backing
- ❑ Ship performance varies with water, depth, channel restrictions and hydrodynamics among other vessels and obstacles.
- ❑ The stability/instability of ship to in-plane motions can occur in (3) modes:



Straight line dynamic stability




Directional course stability



Path stability

Maneuvering models

- ❑ Mathematical maneuvering models are used to assess with the aid of ship maneuvering simulator the ship behavior, to train navigating officers and to develop a ship auto-pilot dedicated
 - ✓ *The model can be complicated, consisting of three non-linear, coupled first order differential equations*
- ❑ For directional stability and maneuverability the only purpose is to describe yaw and sway as accurately as necessary only for this purpose
- ❑ These models are coded for use with design software
- ❑ Turning circle simulation is an important model to validate ship performance



Simple kinematic model assumptions


- ❑ Calm water conditions are used in 3-DOF
 - ✓ surge - translation along x-axis;
 - ✓ sway - translation along y-axis and
 - ✓ yaw - rotation around z-axis.

- ❑ **Heel** is usually disregarded, although it may be important during manoeuvring if it is higher than 10 degrees; wind is an added feature

- ❑ The **drift angle** (the angle between the path of the center of gravity and the middle line plane of the ship) should not show large fluctuations

- ❑ The **rudder angle**, required to compensate for external disturbances by wind and waves, should not be too large

- ❑ **Forward speed effects may be considered**



Translation or rotation	Axis	Description	Positive direction
Translation	Along x	Surge	Forwards
	Along y	Sway	To starboard
	Along z	Heave	Downwards
Rotation	About x	Roll	Starboard side down
	About y	Pitch	Bow up
	About z	Yaw	Bow to starboard

Rudder Forces

- ❑ A rudder is a fin that produces **lift and drag**
- ❑ Rudders produce large turning forces in comparison to their size. These forces give rise to the rudder moment which is influenced by the choice of the balance ratio of Rudder Area forward of the rudder stock and the Total Rudder Area.




Figure 4.3: Forces on a Rudder Section

$$\begin{aligned}
 P &= \sqrt{L^2 + D^2} = \sqrt{N^2 + T^2} \\
 N &= L \cos \alpha + D \sin \alpha \quad \text{and} \quad C_N = C_L \cos \alpha + C_D \sin \alpha \\
 T &= D \cos \alpha - L \sin \alpha \quad \text{and} \quad C_T = C_D \cos \alpha - C_L \sin \alpha
 \end{aligned}$$

- ❑ *This ratio usually varies between 0.25-0.27 for most ships.*

- ❑ Structural considerations, costs, the need for additional stabilizing side forces provided by a horn and the considerations may require use of other types of rudders such as the semi-suspended (or horn) rudder. The horn type is also favored for operations in ice

$$L = \frac{1}{2} \rho C_L A_R V_R^2, \quad D = \frac{1}{2} \rho C_D A_R V_R^2,$$

$$C_L = \frac{2\pi\Lambda(\Lambda+1)}{(\Lambda+2)^2} \sin(\delta+\gamma), \quad C_D = 1.1 \frac{C_L^2}{\pi\Lambda} + C_{D0},$$

- ❑ This force causes further turning of a ship with causes additional attack of angle to the flow and turns the ship

$$C_{D0} = 2.5C_F = 2.5 \frac{0.075}{(\log Rn - 2)^2},$$

IMO Requirements

“The IMO agreed that it would be permissible to demonstrate compliance with the standards by predicting trial performance through model tests and/or computer simulation. Moreover, when acceptable methods of prediction have demonstrated compliance with the standards, the results of full-scale trials would not disqualify a ship.”

4.4 Maneuverability Activities of IMO

During the last three decades, the IMO (International Maritime Organization) has been active in dealing with the following aspects on ship maneuverability, which are vital to achieve its objectives of safer shipping and cleaner oceans:

1. Maneuvering information aboard ships in order to enhance the safety of navigation.
2. Impaired maneuverability of tankers to reduce the risk of marine pollution.
3. Maneuvering standards for ship designers to ensure that no ships have maneuvering properties that may constitute a safety risk.

Many resolutions with respect to maneuverability of ships were initiated by the IMO Sub-Committee on Ship Design and Equipment and by the IMO Marine Safety Committee, which were adopted by the IMO Assembly; for detailed information see a paper of [Srivastava, 1993] and references given there. However, the IMO gives recommendations and guidelines only; they can not make international laws, the final decision has to be made by the individual Governments.

4.4.1 Maneuverability Information On-Board Ships

The value of readily available maneuvering information on the ship's bridge can not be overemphasized as it is of crucial importance to the master, navigating officers and pilots for discharging their duties efficiently and enhancing the safety of navigation.

Having regard to the variety of circumstances that a ship may encounter and the ship's characteristic maneuvering capabilities, the IMO Assembly adopted in 1968 in Resolution A.160 on "Recommendation on Data Concerning Maneuvering Capabilities and Stopping Distances of Ships". The Governments were urged to ensure that the master and the

Mathematical background

- The forces and velocities are often scaled so that we can handle both model and full-scale with same parameters ($q = \rho u^2/2$, speed is initial speed)

$$\begin{Bmatrix} X' \\ Y' \\ K' \\ N' \end{Bmatrix} = \frac{1}{q \cdot L^2} \begin{Bmatrix} X \\ Y \\ K/L \\ N/L \end{Bmatrix} \quad \text{or} \quad \begin{Bmatrix} C_X \\ C_Y \\ C_K \\ C_N \end{Bmatrix} = \frac{1}{q \cdot L \cdot T} \begin{Bmatrix} X \\ Y \\ K/L \\ N/L \end{Bmatrix}$$

- Then the force coefficients can be determined with testing of CFD simulations in still water, resulting in e.g.

$$v' = v/u; \quad r' = r \cdot L/u; \quad \dot{u}' = \dot{u} \cdot L/u^2; \quad \dot{v}' = \dot{v} \cdot L/u^2; \quad \dot{r}' = \dot{r} \cdot L^2/u^2$$

$$Y' = Y'_v \cdot \dot{v}' + Y'_r \cdot \dot{r}' + Y'_{\dot{v}} \cdot v' + Y'_{\dot{v}^3} \cdot (v')^3 + Y'_{v\dot{v}^2} \cdot v' \cdot (v')^2 + Y'_{v\dot{v}^2} \cdot v' \delta^2$$

$$+ Y'_r \cdot r' + Y'_{r^3} \cdot (r')^3 + \dots$$

Table 5.2 Non-dimensional hydrodynamic coefficient of four ship models (Wolff (1981)); values to be multiplied by 10^{-6}

Model of	Tanker	Series 60	Container	Ferry
Initial F_n	0.145	0.200	0.159	0.278
m'	14622	11432	6399	6765
$X'_{\dot{v}} m'$	365	57	-127	-116
$l'_{\dot{v}} m'$	766	573	329	319
$X'_{\dot{v}} m'$	-1077	-1064	0	0
$X'_{\dot{v}^2}$	-5284	0	0	0
$X'_{\dot{v}^3}$	-2217	-2559	-1320	-4336
$X'_{\dot{v}^2}$	1510	0	1179	-2355
$X'_{\dot{v}^3}$	0	-2851	0	-2594
$X'_{\dot{v}^2}$	-889	-3908	-1355	-3279
$X'_{\dot{v}^2}$	237	-838	-151	-571
$X'_{\dot{v}^2}$	-1598	-1346	-696	-2879
$X'_{\dot{v}^2}$	0	-1833	-2463	-2559
$X'_{\dot{v}^2}$	2001	2536	0	3425
$X'_{\dot{v}^2}$	0	0	-470	-734
$X'_{\dot{v}^2}$	9478	7170	3175	4627
$X'_{\dot{v}^2}$	1017	942	611	877
$X'_{\dot{v}^2}$	-482	-372	-340	-351
$X'_{\dot{v}^2}$	745	0	0	0
$X'_{\dot{v}^2}$	0	0	-207	0
$X'_{\dot{v}^2}$	0	-270	0	0
$X'_{\dot{v}^2}$	48	0	0	-19
$X'_{\dot{v}^2}$	166	0	0	0
$X'_{\dot{v}^2}$	0	150	0	0
$X'_{\dot{v}^2}$	-4717	0	0	0
$X'_{\dot{v}^2}$	-365	0	0	0
$X'_{\dot{v}^2}$	1164	2143	0	0
$X'_{\dot{v}^2}$	-118	0	0	0
$X'_{\dot{v}^2}$	-278	0	0	0
$X'_{\dot{v}^2}$	0	621	213	2185
$X'_{\dot{v}^2}$	0	0	-3865	0
$X'_{\dot{v}^2}$	0	0	-447	0

Longitudinal forces X

Model of	Tanker	Series 60	Container	Ferry
$N'_{\dot{v}}$	-523	326	239	426
$N'_{\dot{v}^2}$	2311	1945	5025	10049
$N'_{\dot{v}^2}$	-576	-461	-401	-231
$N'_{\dot{v}^2}$	-130	-250	132	0
$N'_{\dot{v}^2}$	67	9	0	0
$N'_{\dot{v}^2}$	-144	37	8	-36
$N'_{\dot{v}^2}$	-5544	-6570	-3800	-3919
$N'_{\dot{v}^2}$	-132	0	0	0
$N'_{\dot{v}^2}$	-2718	-16602	-23865	-33857
$N'_{\dot{v}^2}$	0	-1146	-2179	-3666
$N'_{\dot{v}^2}$	3448	4421	-4586	0
$N'_{\dot{v}^2}$	2317	0	1418	570
$N'_{\dot{v}^2}$	-3074	-2900	-1960	-2579
$N'_{\dot{v}^2}$	0	-45	0	0
$N'_{\dot{v}^2}$	-865	-1919	-729	-2253
$N'_{\dot{v}^2}$	0	0	-473	0
$N'_{\dot{v}^2}$	913	0	0	0
$N'_{\dot{v}^2}$	-16196	-20530	-27858	-60110

Transverse forces Y

Model of	Tanker	Series 60	Container	Ferry
$N'_{\dot{v}^2}$	-324	0	-404	237
$N'_{\dot{v}^2}$	-1402	-1435	-793	-1621
$N'_{\dot{v}^2}$	0	-138	0	-73
$N'_{\dot{v}^2}$	-1641	3907	0	0
$N'_{\dot{v}^2}$	-536	0	0	0
$N'_{\dot{v}^2}$	2220	-2622	652	2886
$N'_{\dot{v}^2}$	0	0	-6918	-2950
$N'_{\dot{v}^2}$	-855	0	-1096	-329
$N'_{\dot{v}^2}$	2321	1856	0	2259
$N'_{\dot{v}^2}$	0	-568	0	0
$N'_{\dot{v}^2}$	316	0	0	0
$N'_{\dot{v}^2}$	-1538	-1964	0	-1382
$N'_{\dot{v}^2}$	0	5328	8103	0
$N'_{\dot{v}^2}$	0	0	-1784	0
$N'_{\dot{v}^2}$	-394	0	0	0
$N'_{\dot{v}^2}$	384	-1030	0	0
$N'_{\dot{v}^2}$	-27133	-13452	0	0
$N'_{\dot{v}^2}$	0	-476	0	-1322

Mathematical background

- For small deviations from initial, straight path, the motions can be approximated with

$$(X'_u - m')\dot{u}' + X'_u \Delta u' + X'_n \Delta n' = 0$$

$$(Y'_v - m')\dot{v}' + (Y'_r - m'x'_G)\dot{r}' + Y'_v v' + (Y'_r - m')r' = -Y'_\delta \delta$$

- where $m' = m / (1/2 \rho L^2)$, $I'_{zz} = I_{zz} / (1/2 \rho L^5)$ $(N'_v - m'x'_G)\dot{v}' + (N'_r - I'_{xx})\dot{r}' + N'_v v' + (N'_r - m'x'_G)r' = -N'_\delta \delta$

- For the linearized case, we get $I_{zz} = \int (x^2 + y^2) dm$

$$M' \ddot{\mathbf{u}}' + D' \dot{\mathbf{u}}' = \vec{r}' \delta + \begin{Bmatrix} T' \\ T' x'_t \end{Bmatrix}$$

Mass

Motion


$$M' = \begin{bmatrix} -Y'_v + m' & -Y'_r + m'x'_G \\ -N'_v + m'x'_G & -N'_r + I_{zz} \end{bmatrix}; \quad \ddot{\mathbf{u}}' = \begin{Bmatrix} \dot{v}' \\ \dot{r}' \end{Bmatrix}$$

$$D' = \begin{bmatrix} -Y'_v & -Y'_r + m' \\ -N'_v & -N'_r + m'x'_G \end{bmatrix}; \quad \vec{r}' = \begin{Bmatrix} Y'_\delta \\ N'_\delta \end{Bmatrix} \quad \begin{Bmatrix} T' \\ T' x'_t \end{Bmatrix}$$

Damping

Rudder

Thrusters



Mathematical background

□ Regression formulae for the coefficients

$$Y'_v = -\pi(T/L)^2 \cdot (1 + 0.16C_B \cdot B/T - 5.1(B/L)^2)$$

$$Y'_r = -\pi(T/L)^2 \cdot (0.67B/L - 0.0033(B/T)^2)$$

$$N'_v = -\pi(T/L)^2 \cdot (1.1B/L - 0.041B/T)$$

$$N'_r = -\pi(T/L)^2 \cdot (1/12 + 0.017C_B \cdot B/T - 0.33B/L)$$

$$Y'_v = -\pi(T/L)^2 \cdot (1 + 0.40C_B \cdot B/T)$$

$$Y'_r = -\pi(T/L)^2 \cdot (-0.5 + 2.2B/L - 0.08B/T)$$

$$N'_v = -\pi(T/L)^2 \cdot (0.5 + 2.4T/L)$$

$$N'_r = -\pi(T/L)^2 \cdot (0.25 + 0.039B/T - 0.56B/L)$$

□ The non-linear model involves second order terms of the velocities and rudder angle, but also cross-products of the different components. The equations are (see for details Matusiak book)

$$\begin{aligned} X = & X_{\dot{u}}\dot{u} + X_u u + X_{uu}u^2 + X_{uuu}u^3 + X_{vv}v^2 + X_{rr}r^2 + X_{\delta\delta}\delta^2 \\ & + X_{vr}vr + X_{v\delta}v\delta + X_{r\delta}r\delta + X_{vuu}v^2u + X_{rru}r^2u + X_{\delta\delta u}\delta^2u \\ & + X_{r\delta u}r\delta u + X_{rvu}rvu + X_{v\delta u}v\delta u + X_{r\delta v}r\delta v. \end{aligned}$$

$$\begin{aligned} Y = & Y_{uu}u^2 + Y_v\dot{v} + Y_r\dot{r} + Y_vv + Y_rr + Y_\delta\delta + Y_{\delta u}\delta u + Y_{vu}vu + Y_{ru}ru + Y_{vuu}vu^2 \\ & + Y_{ruu}ru^2 + Y_{\delta uu}\delta u^2 + Y_{vvv}v^3 + Y_{rrr}r^3 + Y_{\delta\delta\delta}\delta^3 + Y_{rr\delta}r^2\delta + Y_{vrr}vr^2 \\ & + Y_{rvv}rv^2 + Y_{\delta vv}\delta v^2 + Y_{vr\delta}vr\delta + Y_{\delta\delta r}\delta^2r + Y_{\delta\delta v}\delta^2v. \end{aligned}$$

$$\begin{aligned} N = & N_{uu}u^2 + N_v\dot{v} + N_r\dot{r} + N_vv + N_rr + N_\delta\delta + N_{\delta u}\delta u + N_{vu}vu + N_{ru}ru + N_{vuu}vu^2 \\ & + N_{ruu}ru^2 + N_{\delta uu}\delta u^2 + N_{vvv}v^3 + N_{rrr}r^3 + N_{\delta\delta\delta}\delta^3 + N_{rr\delta}r^2\delta + N_{vrr}vr^2 \\ & + N_{rvv}rv^2 + N_{\delta vv}\delta v^2 + N_{vr\delta}vr\delta + N_{\delta\delta r}\delta^2r + N_{\delta\delta v}\delta^2v. \end{aligned}$$

CFD & Model tests

- ❑ Linear system leads often to good results in terms of comparing different design alternatives, but unsatisfactory results when accuracy is concerned


- ❑ CFD is the future of the maneuvering predictions as well
 - ✓ Lifting surface methods (inviscid flow about a plate)
 - ✓ Lifting body methods (source distributions to model body thickness)
 - ✓ Field methods (accounting also the viscous effects)

- ❑ These methods can be coupled to account free-surface effects

- ❑ Experiments should represent the load conditions ship has during its lifetime. The site of experiments should have
 - ✓ Adequate water depth
 - ✓ Enough distance to geographical flow disturbances
 - ✓ Mild wave and wind conditions
 - ✓ No currents

Type of Test	IMO A.601	IMO A.751	ITTC 1975	SNAME 1989	Norsk Standard	Japan RR
1 Turning Test	✓	✓	✓	✓	✓	✓
2 Z-Maneuver Test (Kempf)	✓	✓	✓	✓	✓	✓
3 Modified Z-Maneuver Test						✓
4 Direct Spiral Test (Dieudonné)			✓	✓	✓	✓
5 Reverse Spiral Test (Bech)			✓	✓	✓	✓
6 Pull-Out Test	✓		✓	✓		
7 Stopping Test	✓	✓	✓	✓	✓	✓
8 Stopping Inertia Test	✓				✓	✓
9 New Course Keeping Test	✓					✓
10 Man-Overboard Test	✓					
11 Parallel Course Maneuver Test	✓					
12 Initial Turning Test				✓		
13 Z-Maneuver Test at Low Speed	✓			✓		✓
14 Accelerating Turning Test	✓		✓			
15 Acceleration/Deceleration Test	✓			✓		
16 Thruster Test	✓		✓	✓	✓	
17 Minimum Revolution Test	✓			✓	✓	
18 Crash Ahead Test	✓			✓	✓	✓

Table 4.1. Recommended Maneuvering Tests by Various Organizations



Sea Trials

Carried out after the dock tests to demonstrate proper operation of the main and auxiliary machinery, including monitoring, alarm and safety systems, under realistic conditions.



The trials are also to demonstrate that any vibration which may occur within the operating speed range is acceptable.



Zig-Zag / Turning maneuvering test

□ **Zig zag** : To express course changing and course keeping qualities Information obtained:

- ✓ initial turning time,
- ✓ time to second execute,
- ✓ the time to check yaw
- ✓ the angle of overshoot.
- ✓ Steering indices K (gain constant) and T (time constant) for the linearized response model




□ **Turning** : to determine the turning characteristics of the ship at different speeds and rudder angles. Information obtained:

- ✓ advance,
- ✓ transfer,
- ✓ tactical diameter,
- ✓ steady turning diameter,
- ✓ final ship speed
- ✓ turning rate in the steady state



Direct spiral, new course keeping, acceleration tests

- ❑ **Direct Spiral** : The purpose is to find out if the ship is directionally stable or not. Important parameters are width and height of the loop for an unstable ship
- ❑ **New course keeping** : The test provides info for changing a ship course. The obtained data is ship heading versus advance and transfer
- ❑ **Acceleration** : These tests determine speed and reach along the projected approach path versus elapsed time for a series of acceleration/deceleration runs using various engine set-ups



Summary

- ❑ The speed of a ship in calm water is defined by her **(1) Resistance: wave + friction (2) Propeller efficiency (3) Power of engines**. In rough weather the resistance may be changed by the action of **(1) Waves, (2) Wind, (3) Current (4) Ice**

- ❑ Typically, the change of load also affects the propeller efficiency and furthermore the speed we can obtain with certain main engine. This is called involuntary loss of speed which can cause economically substantial losses

- ❑ Three key aspects for good controllability:
 - ✓ Realistic specification and criteria for course-keeping, manoeuvring and speed change
 - ✓ Design of hull and control equipment to meet these requirements
 - ✓ Validation with full-scale sea-trials to compare with specification and predictions

- ❑ Controllability covers all aspects related to ship's: **(1) Trajectory (2) Speed (3) Orientation (4) Positioning and station keeping**.

- ❑ Performance varies with water, depth, channel restrictions and hydrodynamics among other vessels and obstacles

Thank you !!